


Resolving PRSIM Issues

December 4, 2020 Initial



Powered by Manitoba Hydro International Ltd. 211 Commerce Drive Winnipeg, Manitoba R3P 1A3 Canada mhi.ca





Contents

1.	INTRODUCTION	.1
1.1	Overview	.1
1.2	RELATED SUPPORT DOCUMENTS	.1
2.	PRSIM USAGE ISSUES	.2
2.1	RECEIVING AN "COORDINATES SHOULD NOT EXCEED THE CANVAS SIZE" ERROR MESSAGE	.2



1. Introduction

1.1 Overview

This manual presents known issues and solutions related to using PRSIM. It is intended to be a continuously developing diagnostic tool as licensing evolves. If you encounter any issues that are not covered herein, please forward the details to our Support Desk (<u>support@mhi.com</u>).

1.2 Related Support Documents

Refer to this <u>article</u> for other, related, support documents.




2. PRSIM Usage Issues

2.1 Receiving a "Coordinates should not exceed the canvas size..." Error Message

Problem

The following error displays:




Cause

The PRSISM canvas size is limited to be consistent with the PSCAD canvas size, to maintain compatibility between PRSIM output and PSCAD input.

Solution (1) Select the Appropriate Canvas Size in Relation to the PSCAD Version

• Select the PSCAD target version, located on the "Home" tab:



• Select the corresponding canvas size:

Cana Semaption East the class setting. East the class setting. <theast class="" setting.<="" th="" the=""> East the class</theast>	Add Bus	1.1.1.1.1			I HAT ALL ALL ALL ALL ALL ALL ALL ALL ALL A		
Cot Control Page out-tending Not-tendender Not-tendender Page out-tending Cottor Page out-tending Not-tendender Not-tendender Page out-tending Cottor Page out-tending Not-tendender Not-tendender Value out-tending Cottor Page out-tending Not-tendender Not-tendender Value out-tending Cottor Not-tendender Not-tendender Not-tendender Not-tendender Not-tendender Not-tendender Not-tendender Not-tendender Not-tendender Not-tendeder Not-tendeder Not-tendeder Not-tendeder Not-tende Not-tende Not-tende Not-tende Not-tende	Canvas Settings	ngs_		General Coordinate Import	21 (3 # m		
Under Och-Z Reich Cof-Y Prot Arget Prot	Copy	Ctrl=X Ctrl=C Ctrl=V			Show power levels PQ display precision Show definition names > Bus Annotations	2 decimal places	
Net Bays Net Theory Test Holp Ti Advah T5		Ctrl+Z Ctrl+Y			Show bus names		
Page Fig Refeeth F5 Set end F5 Set end Set end Add Set Set End Set end Add Set End Set End					v Overlays	Not diskayed	
843 (1017) See (24110-22) See (24120-22) Adjust the same of the schematic/co-area (Deve)							
Size D(A1 (22:34) Adjusts the size of the schematic (Oversize (34:64)					Orientation	B/A3 (11x17)	
					Size Adjusts the size of the schemat	P(41/22v34)	

Solution (2) Move Some of the System into a Subpage

Select part of your system, and push it into a subpage. This will free up some space to help display the rest of your system.

Continued...



Solution (3) Move Some of the System into a Schematic

Create multiple schematics for different parts of the network. Using this option results in multiple PSCAD cases that must be linked properly later on.

Solution (4) Resize the System on the Loadflow Platform Canvas

If the size of the networks allows, users may avoid relying on the subpage or schematic options by redistributing the system components on the PSSE or PowerFactory DIgSILENT canvas. This will allow reducing the required space for the case being loaded into PRSIM.



DOCUMENT TRACKING

Rev.	Description	Date
0	Initial	04/Dec/2020

Copyright © 2020 Manitoba Hydro International Ltd. All Rights Reserved.